

APPLICATION SPECIFICATION- ICO-HI GROUT BL

1. Obtain clean surface by shotblasting, scarifying or by other mechanical means. For heavily oil-or grease-saturated floor, clean with a heavy duty degreasing agent prior to mechanical cleaning.
2. No primer is necessary. However, if new concrete (less than 28 day cure) priming is advisable (use Primer LV FC) to reduce outgassing.
3. Mix Parts A and B in a paddle-style mixer for at least 30-60 seconds, then add aggregate and dry pigment and mix for another 30-60 seconds, until mix is uniform in color and consistency.
4. As a bedding mortar, apply with a quarter inch V-notched trowel to achieve the recommended one eighth inch thick bed. Do not lay more than an area which can be tiled before the mortar starts to stiffen (approximately 30 minutes at 75°F). Approximately twenty eight - 36 pound kits are required per 1000 SF of floor area.
5. When using the bricklayers method, butter one side and one end of the brick, set into bedding mortar and push up against adjacent brick so as to force epoxy mortar up the side and end of the brick or tile. Strike off any excess.
6. For cleanup, allow the grout to slightly stiffen (approximately 30 minutes), then use a rag or stiff abrasive pad moistened with solvent, i.e., toluene. Do not allow to harden. If allowed to harden then a special paint stripper must be used. Consult factory.
7. A clear residue will be left on the brick. If this is objectionable, use waxed brick or tile and steam clean the next day.

Note: Do not apply below 50°F.